



A minute is a long time.

Two minutes must be more than twice as long to some pilots because they don't wait out the 2-minute idle before shutting down the T-53 engine.

If you don't let the EGT stabilize, some critical parts—like the gas producer nozzle—will crack. The bird will be EDP'ed after a hot-end inspection.

Time the idle, man.