



So, lube the sleeve splines during installation of the scissors and sleeve assembly. In addition, take off the protective boot and smear grease on the exposed splines during the Periodic inspection. You'll find that word in the Huey lube chart.

