



HEY... YOUR COATING WON'T COME OFF!

# Super Korpon OK!



'COURSE NOT! IT'S SUPER KORPON!

When you Huey mechs install the elevator on your bird, you have to remove any zinc chromate primer that may have been applied to the horn or spar.

That's the word in Para 2-293 of TM 55-1520-210-23 (Feb 79).

If that yellow-green coating inside the bore resists removal with your application of methyl-ethyl-ketone on a rag, tho, cease and desist!

The coating is not zinc chromate—it's Super Korpon Epoxy Primer, now being used by the manufacturer.

Both products look the same, so how do you tell the difference? Easy! Methyl-ethyl-ketone will quickly cut into zinc chromate.

Not so with Super Korpon...it's a tough finish that will help prevent seizure of the spar in the horn.

