

CABIN INTERIOR

FIRE EXTINGUISHER - Missing pin. Out-ofdate inspection tag. Loose bracket. Broken



FIRST AID KITS-Missing, Missing safety and inspection tag.

SEAT BELTS-Attached loosely to the floor. Ripped; torn. Hook 'em up if seats




FOREIGN OBJECTS-Loose tools, helmets, ammo, clothing. (Stow helmet bag under pilot's seat.) Loose, flapping soundproofing panels. Damaged sockets, buttons.



CREW AND CARGO DOORS-Damaged too 'n' bottom pins. Window ejection handle up, safety missing. Dents, cracks, other damage. Rollers or sliders do the stutter step when cargo doors open or close. Doors won't stay put open or shut. Latches don't fit flush.

> CO-PILOT'S DOOR-Missing jettisonable door pins. Rubber door stops deteriorated. Cracks in door hinges. Emergency jack won't work. Missing copper safety wire.

PITOT TUBE AND STATIC PORTS-Covered. Doublecheck for dirt buildup.



CABIN TOP-Holes, rips, tears, buckling. Ventilators get a second look. Anyone put his brogans thru 'em? Same goes for NO-STEP spots, Ventsclogged. Broken, damaged antennas and anti-collision


CHECK VENT LINES

battery connections.

Balloned battery cover. Dirty, loose

CABIN EXTERIOR-Dents, holes in fuse-

lage. Loose, missing weatherstripping.



LANDING GEAR-Damaged steps and fittings. Deep scratches, scuffs, nicks, dents

on tubes. Skids out of line. Missing cush-

ions on skid brackets. Missing broken

crosstube bolt. Broken skid shoe bolt.

TIP: Skid shoes must overlap the right way so they'll not catch on PSP or ground wires.