

(1) ILLUSTRATION		(2)	(3)	(4)	(5)	(6) DESCRIPTION	(7)	(8)
(A) FIG NO.	(B) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	FSCM	PART NUMBER	USABLE ON CODE	U/M	QTY INC IN UNIT
226	227	PAOZZ	5305-00-993-1851	96906	MS35207-267	..SCREW, MACHINE	UHH,UHV	EA 4
226	227A	PAOZZ	5365-00-134-3861	97499	205-075-157-1	..SHIM U/O PN 205-075-036-11 U/W PN 204-075-152-1	UHH,UHV	EA 1
226	228	AOOOO	6625-00-733-2581	97499	204-075-152-1	..SHUNT ASSEMBLY	UHH,UHV	EA 1
226	229	MOOZZ		97499	204-075-152-3	..SHUNT	UHH,UHV	EA 1
226	230	PAOZZ	5306-00-838-0660	96906	MS20074-06-07	..BOLT, MACHINE	UHH,UHV	EA 2
226	230A	PAOZZ	6150-00-437-7524	97499	205-075-160-1	..BUS, CONDUCTOR U/O PN 205-075-036-11	UHH,UHV	EA 1
226	231	XCFZZ		97499	205-075-101-1	..PANEL INSTL, A-C CIRCUIT BREAKER U/O PN 205-075-006-1	UHH,UHV	EA 1
226	231	XCFZZ		97499	205-075-101-5	..PANEL INSTL, A-C CIRCUIT BREAKER U/O PN 205-075-008-1,-3,-5, & 205-075-013-1	UHH,UHV	EA 1
226	231	XCFZZ		97499	205-075-101-9	..PANEL INSTL, A-C CIRCUIT BREAKER U/O PN 205-075-013-3	UHH,UHV	EA 1
226	231	XCFZZ		97499	205-075-101-13	..PANEL INSTL, A-C CIRCUIT BREAKER U/O PN 205-075-018-1,-3, 205-075-032-1,-3, & -15	UHH,UHV	EA 1
226	231	XCFZZ		97499	205-075-101-17	..PANEL INSTL, A-C CIRCUIT BREAKER U/O PN 205-075-032-9, & -13	UHH,UHV	EA 1
226	231	XCFZZ		97499	205-075-101-21	..PANEL INSTL, A-C CIRCUIT BREAKER U/O PN 205-075-036-1	UHH,UHV	EA 1
226	231	XCFZZ		97499	205-075-101-25	..PANEL INSTL, A-C CIRCUIT BREAKER U/O PN 205-075-036-3	UHH,UHV	EA 1
226	231	XCFZZ		97499	205-075-101-29	..PANEL INSTL, A-C CIRCUIT BREAKER U/O PN 205-075-036-7,-9, & -11	UHH,UHV	EA 1
226	232	PAOZZ	5305-00-984-6192	96906	MS35206-244	..SCREW, MACHINE	UHH,UHV	EA 8
226	233	PAOZZ	5310-00-184-9002	88044	AN960PDL	..WASHER, FLAT	UHH,UHV	EA 8
226	234	PBOZZ	5305-00-208-3716	96906	MS35214-25	..SCREW, MACHINE	UHH,UHV	EA 8
226	235	PAOZZ	5310-00-877-5822	96906	MS21044B06	..NUT, SELF-LOCKING, HEXAGON	UHH,UHV	EA 6
226	236	PAOZZ	5310-00-187-2398	88044	AN960PDL	..WASHER, FLAT	UHH,UHV	EA 6
226	237	AOOOZ	1560-00-987-5233	97499	205-075-101-3	..PANEL ASSY U/O PN 205-075-101-1	UHH,UHV	EA 1
226	237	AOOOZ	1560-00-567-2954	97499	205-075-101-7	..PANEL ASSY U/O PN 205-075-101-5	UHH,UHV	EA 1
226	237	AOOOZ	6110-00-911-7678	97499	205-075-101-11	..PANEL ASSY U/O PN 205-075-101-9	UHH,UHV	EA 1
226	237	AOOOZ	5925-00-947-3489	97499	205-075-101-15	..CIRCUIT PANEL BOX U/O PN 205-075-101-13	UHH,UHV	EA 1
226	237	AOOOZ	6110-00-891-3122	97499	205-075-101-19	..PANEL ASSY U/O PN 205-075-101-17	UHH,UHV	EA 1
226	237	AOOOO		97499	205-075-101-23	..PANEL ASSY U/O PN 205-075-101-21	UHH,UHV	EA 1
226	237	AOOOO		97499	205-075-101-27	..PANEL ASSY U/O PN 205-075-101-25	UHH,UHV	EA 1
226	237	AOOOO		97499	205-075-101-31	..PANEL ASSY U/O PN 205-075-101-29	UHH,UHV	EA 1
226	238	AOOOO		97499	205-075-404-3	..WIRING ASSY U/O PN 205-075-101-3	UHH,UHV	EA 1
226	238	AOOOO		97499	205-075-404-9	..WIRING ASSY U/O PN 205-075-101-7	UHH,UHV	EA 1
226	238	AOOOO		97499	205-075-404-11	..WIRING ASSY U/O PN 205-075-101-11	UHH,UHV	EA 1
226	238	AOOOO		97499	205-075-404-13	..WIRING ASSY U/O PN 205-075-101-15	UHH,UHV	EA 1
226	238	AOOOO		97499	205-075-404-15	..WIRING ASSY U/O PN 205-075-101-19,-23, & -27	UHH,UHV	EA 1
226	238	AOOOO		97499	205-075-404-19	..WIRING ASSY U/O PN 205-075-101-31	UHH,UHV	EA 1
226	239	PAOZZ	5940-00-813-0698	96906	MS25036-101TERMINAL, LUG U/O PN 205-075-404-19	UHH,UHV	EA 5
226	240	PAOZZ	5940-00-204-8996	96906	MS25036-102TERMINAL, LUG U/O PN 205-075-404-3, & -9	UHH,UHV	EA 1
226	240	PAOZZ	5940-00-204-8996	96906	MS25036-102TERMINAL, LUG U/O PN 205-075-404-11, -13, & -15	UHH,UHV	EA 5
226	241	PAOZZ	5940-00-557-1829	96906	MS25036-149TERMINAL, LUG U/O PN 205-075-404-3	UHH,UHV	EA 39
226	241	PAOZZ	5940-00-557-1829	96906	MS25036-149TERMINAL, LUG U/O PN 205-075-404-9	UHH,UHV	EA 1