

(1) ILLUSTRATION		(2)	(3)	(4)	(5)	(6)	(7)	(8)
(A) FIG NO.	(B) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	FSCM	PART NUMBER	DESCRIPTION	USABLE ON CODE	QTY INC IN UNIT
226	574	PBOZZ	6145-00-578-7514	81349	M5086/2-12-9	.WIRE, ELECTRICAL	UHH,UHV	FT V
226	575	PAOZZ	6145-00-578-6602	81349	M5086/2-18-9	.WIRE, ELECTRICAL	UHH,UHV	FT V
226	576	PBOZZ	6145-00-851-8505	96906	MS25190B20	.WIRE, ELECTRICAL	UHH,UHV	FT V
226	577	XDOZZ	5935-00-240-0173	96906	MS3057-4A	.CLAMP, CABLE	UHH,UHV	EA 1
226	578	XCFZZ		97499	205-075-108-1	EQUIPMENT INSTL, AFT ELECTRICAL COMPARTMENT U/O PN 205-075-008-1 SEE FIG.272 & 273 FOR BREAKDOWN	UHH,UHV	EA 1
226	578	XCFZZ		97499	205-075-109-1	EQUIPMENT INSTL, AFT ELECTRICAL COMPARTMENT U/O PN 205-075-008-1, -3, -5 & 205-075-013-1, & -3 SEE FIG.272 & 273 FOR BREAKDOWN	UHH,UHV	EA 1
226	578	XCFZZ		97499	205-075-112-1	EQUIPMENT INSTL, AFT ELECTRICAL COMPARTMENT U/O PN 205-075-018-1, & -3 SEE FIG.273 & 274 FOR BREAKDOWN	UHH,UHV	EA 1
226	578	XCFZZ		97499	205-075-112-3	EQUIPMENT INSTL, AFT ELECTRICAL COMPARTMENT U/O PN 205-075-032-1, -3, -13 & -15 SEE FIG.274 FOR BREAKDOWN	UHH,UHV	EA 1
226	578	XCFZZ		97499	205-075-112-7	EQUIPMENT INSTL, AFT ELECTRICAL COMPARTMENT U/O PN 205-075-032-9 SEE FIG.274 FOR BREAKDOWN	UHH,UHV	EA 1
226	578	XCFZZ		97499	205-075-112-9	EQUIPMENT INSTL, AFT ELECTRICAL COMPARTMENT U/O PN 205-075-036-1, -3, -7, -9, & -11 SEE FIG.274 FOR BREAKDOWN	UHH,UHV	EA 1
226	578	XCFZZ		97499	205-075-112-11	EQUIPMENT INSTL, AFT ELECTRICAL COMPARTMENT U/O PN 205-075-036-1, -3, -7, -9 & -11 SEE FIG.274 FOR BREAKDOWN	UHH,UHV	EA 1
226	579	MFOZZ	DELETED	97499	205-075-151-1	.BRACKET, CONNECTOR U/O PN 205-075-018-1, -3, 205-075-032-1, -3, -9, -13, 205-075-036-1, -3, -7, -9, & -11	UHH,UHV	EA 3
226	580	PAOZZ	5340-00-993-1470	81996	EAB700D18	.CLAMP, LOOP	UHH,UHV	EA 1
226	581	PAOZZ	5305-00-984-4989	96906	MS35206-229	.SCREW, MACHINE	UHH,UHV	EA 6
226	582	PAOZZ	5305-00-282-2712	88044	AN503-6-8	.SCREW, MACHINE	UHH,UHV	EA 2
226	583	AOOOZ	1560-00-906-0278	97499	205-075-410-13	CABLE ASSY, FILTER NETWORK U/O PN 205-075-013-1-3, 205-075-018-1, -3, 205-075-032-1, -3, -9, -13, 15, 205-075-036-1, -3, -7, -9, & -11	UHH,UHV	EA 1
226	584	PAOZZ	5940-00-813-0698	96906	MS25036-101	.TERMINAL, LUG	UHH,UHV	EA 1
226	585	PAOZZ	5940-01-079-1647	81349	M7928/5-3	.SPLICE, CONDUCTOR	UHH,UHV	EA 1
226	586	XDOZZ		97499	85T4-7-2	.INSULATION TUBE	UHH,UHV	FT 2
226	587	PAOZZ	5915-00-878-0340	80183	JN14-1600B	.FILTER NETWORK	UHH,UHV	EA 1
226	588	PBOZZ	6145-00-851-8505	96906	MS25190B20	.WIRE, ELECTRICAL	UHH,UHV	FT V
226	589	PAOZZ	5340-00-514-3009	88044	AN735D43	.CLAMP, LOOP	UHH,UHV	EA 1
226	590	PAOZZ	5325-00-174-5314	96906	MS35489-5	.GROMMET, NONMETALLIC	UHH,UHV	EA 1
226	591	PBOZZ	5935-00-990-5580	96906	MS3181-14N	.COVER, ELECTRICAL CO	UHH,UHV	EA 2
226	592	PAOZZ	5305-00-958-0586	96906	MS35207-273	.SCREW, MACHINE	UHH,UHV	EA 1
226	593	PAOZZ	5365-00-825-8562	80205	NAS43DD3-132	.SPACER, SLEEVE	UHH,UHV	EA 1
226	594	PAOZZ	5305-00-145-7011	88044	AN503-8-8	.SCREW, MACHINE	UHH,UHV	EA 1
226	595	PAOZZ	5305-00-984-6193	96906	MS35206-245	.SCREW, MACHINE	UHH,UHV	EA 3
226	596	PAOZZ	5310-00-167-0833	88044	AN960-8L	.WASHER, FLAT	UHH,UHV	EA 4
226	597	PAOZZ	5310-00-167-0832	88044	AN960-8L	.WASHER, FLAT	UHH,UHV	EA 4
226	598	XDOZZ		88044	AN500A4-8	.SCREW, MACHINE	UHH,UHV	EA 1
226	599	PAOZZ	5310-00-167-0831	88044	AN960-4L	.WASHER, FLAT	UHH,UHV	EA 4
226	600	PAOZZ	5310-00-807-1475	96906	MS21042L4	.NUT, SELF-LOCKING, EX EXTENDED WASHER, HEXAGON	UHH,UHV	EA 1
226	601	PAOZZ	5325-00-184-9846	96906	MS35489-10	.GROMMET, NONMETALLIC	UHH,UHV	EA 1