


# Make This Washer!

When installing the Huey tail rotor hub and blade, according to Para 5-97 of TM 55-1520-210-23, you have to



use a synthane washer between each pitch change link and the crosshead.

You make the washer from bulk material.

