

PART NUMBER	NOUN
204-001-809-1	BELLCRANK
204-001-825-3	DELETED
204-001-957-1	CONNECTING LINK, RIG
204-010-404-3	COLLAR, SHAFT
204-010-420-1	NUT, PLAIN, ROUND
204-010-437-7	NUT, PLAIN, ROUND
204-010-479-17	PLATE SET, COLLECTIVE
204-010-481-1	NUT, PLAIN, SPLINE
204-010-719-1	NUT, PLAIN, ROUND
204-010-720-3	SLIDER, TAIL ROTOR
204-010-740-5	T/R CONTROL ASSY. QUILL
204-010-742-9	T/R CONTROL TUBE
204-011-003-21	SPAR, MAIN ROTOR BLADE
204-011-003-23	SPAR, MAIN ROTOR BLADE
204-011-102-17	YOKE ASSEMBLY, MAIN ROTOR
204-011-105-1	TRUNNION ASSEMBLY
204-011-108-1	PILLOW BLOCK
204-011-108-3	PILLOW BLOCK
204-011-116-1	NUT
204-011-119-1	BEARING, PLAIN, ROD END
204-011-120-5	PITCH HORN ASSEMBLY
204-011-121-113	MAIN ROTOR GRIP
204-011-121-5	GRIP ASSEMBLY, MAIN
204-011-127-1	LINK ASSEMBLY, MAIN
204-011-128-1	UNIVERSAL, CONTROL L
204-011-135-3	BUSHING, SLEEVE
204-011-136-103	CLEVIS, ROD END
204-011-137-1	TURNBUCKLE BODY
204-011-143-1	ROD, THREADED END
204-011-151-1	BOLT ASSEMBLY, MAIN

Table 1-9. Flight Safety Critical Aircraft Parts (2 of 11).