

(1) ILLUSTRATION		(2)	(3)	(4)	(5)	(6)	(7)	(8)
(A) FIG. NO.	(B) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	FSCM	PART NUMBER	DESCRIPTION USABLE ON CODE	U/M	QTY INC IN UNIT
154	45	PAOZZ	5306-00-722-0393	88044	AN3-4A	. BOLT, MACHINE UHH, UHV	EA	1
154	46	PAOZZ	5340-00-106-2361	97499	205-040-156-3	. CLAMP, LOOP UHH, UHV	EA	1
154	47	MFOZZ	1560-00-915-5852	97499	205-040-170-1	. BRACKET, HOSE SUPPORT UHH, UHV	EA	1
154	48	MFOZZ	1560-00-999-1629	97499	205-040-169-1	. BRACKET, HOSE SUPPORT UHH, UHV	EA	1
154	49	MFOZZ	4730-00-839-0976	00624	375200-6	. COUPLING HALF, QUICK DISCONNECT UHH, UHV	EA	1
154	50	PAOZZ	5310-00-638-2605	96906	MS24400D6	. NUT, PLAIN, HEXAGON UHH, UHV	EA	1
154	51	PAOZZ	5331-00-576-9925	80205	NAS617-6	. PACKING, PREFORMED UHH, UHV	EA	1
154	52	PAOZZ	5310-00-807-1476	96906	MS21042L5	. NUT, SELF-LOCKING, EXTENDED UHH, UHV	EA	2
154	53	PAOZZ	5310-00-167-0836	88044	AN960-516L	. WASHER, HEXAGON UHH, UHV	EA	2
154	54	PAOZZ	5310-00-825-4306	80205	NAS1197-516	. WASHER, FLAT UHH, UHV	EA	2
154	55	PAOZZ	1615-00-829-6845	97499	204-040-367-1	. QUILL ASSEMBLY SEE FIG. 169 FOR BREAKDOWN UHH, UHV	EA	1
154	56	PAODD	5331-00-726-4153	96906	MS29561-237	. PACKING, PREFORMED UHH, UHV	EA	1
154	57	PAOZZ	1615-00-987-5152	97499	205-040-200-1	. QUILL ASEMBLY, TRANSMISSION SEE FIG. 168 FOR BREAKDOWN UHH, UHV	EA	1
154	58	PAODD	5331-00-726-1236	96906	MS29561-248	. PACKING, PREFORMED UHH, UHV	EA	1
154	59	PAOZZ	5305-00-725-3503	96906	MS51964-97	. SETSCREW UHH, UHV	EA	1
154	60	PAOZZ	5306-00-180-0313	88044	AN6-35A	. BOLT, MACHINE UHH, UHV	EA	5
154	61	PAOZZ	5310-00-167-0821	88044	AN960-616	. WASHER, FLAT UHH, UHV	EA	5
154	62	PAOZZ	5310-00-847-2719	80205	NAS1197-616	. WASHER, FLAT UHH, UHV	EA	5
154	63	PAODD	1680-00-183-0834	97499	204-040-016-5	. TRANSMISSION ASSEMBLY, H SEE FIG. 155, 156 & 159 FOR BREAKDOWN UHH, UHV	EA	1
154		PAFDD	8145-00-701-9867	97499	204-030MUSC1	. SHIPPING AND STORAGE CONTAINER UHH, UHV	EA	1