


UH-1 . . .

# Changing Trans Gasket

The transmission oil filter gasket replacement instructions in your Huey's TM are a bit skimpy.


Follow the TM, but use these two extra tips when replacing the gasket, NSN 5330-00-107-5393.

**1.** Make sure you clean all the old gasket material off the mating surfaces. Leftover material causes leaks. Wipe surface dry.



Thoroughly clean mating surfaces

**2.** Check the new gasket closely. If you see indentions, creases or even the smallest of nicks, toss it. You'll quickly get leaks. Instead, get another gasket.



Make sure new gasket has no defects