

ILLUSTRATION		SMR CODE	NATIONAL STOCK NUMBER	FSCM	PART NUMBER	DESCRIPTION	U/M	QTY INC IN UNIT
(A)	(B)							
FIG NO.	ITEM NO.					USABLE ON CODE		
226	241	PAOZZ	5940-00-557-1629	96906	MS25036-149	...TERMINAL LUG U/O PN 205-075-404-11	UHH,UHV	EA 35
226	241	PAOZZ	5940-00-557-1629	96906	MS25036-149	...TERMINAL LUG U/O PN 205-075-404-13	UHH,UHV	EA 37
226	241	PAOZZ	5940-00-557-1629	96906	MS25036-149	...TERMINAL LUG U/O PN 205-075-404-15	UHH,UHV	EA 34
226	241	PAOZZ	5940-00-557-1629	96906	MS25036-149	...TERMINAL LUG U/O PN 205-075-404-19	UHH,UHV	EA 33
226	242	PBOZZ	6145-00-851-8505	96906	MS25190B20	...WIRE, ELECTRICAL	UHH,UHV	FT V
226	242A	PAOZZ	5940-00-143-4771	96906	MS25036-103	...TERMINAL LUG U/O PN 205-075-404-11,-13,-15, & -19	UHH,UHV	EA 2
226	243	PAOZZ	5340-00-761-6417	61864	BS51338K2215	...BUTTON, PLUG U/O PN 205-075-101-3,-7,-11,-19, & -23	UHH,UHV	EA 4
226	243	PAOZZ	5340-00-761-6417	61864	BS51338K2215	...BUTTON, PLUG U/O PN 205-075-101-15, & -27	UHH,UHV	EA 3
226	243	PAOZZ	5340-00-761-6417	61864	BS51338K2215	...BUTTON, PLUG U/O PN 205-075-101-31	UHH,UHV	EA 5
226	243	PAOZZ	5340-00-691-2734	83058	BS51338K5900	...BUTTON, PLUG	UHH,UHV	EA 4
226	244	PAOZZ	9905-00-845-0959	97499	204-075-164-5	...PLATE, IDENTIFICATION U/O PN 205-075-101-3,-7,-11, & -31	UHH,UHV	EA 1
226	245	PAOZZ	9905-00-924-5637	97499	204-075-164-35	...PLATE, IDENTIFICATION U/O PN 205-075-101-15, & -19	UHH,UHV	EA 1
226	246	PAOZZ	9905-00-883-1685	97499	204-075-164-45	...PLATE, IDENTIFICATION U/O PN 205-075-101-23	UHH,UHV	EA 1
226	246A	PAOZZ		97499	204-075-164-43	...PLATE, IDENTIFICATION	UHH,UHV	EA 1
226	246B	PAOZZ		97499	204-075-164-47	...PLATE, IDENTIFICATION	UHH,UHV	EA 1
226	247	PAOZZ	9905-00-845-0960	97499	204-075-164-3	...PLATE, IDENTIFICATION U/O PN 205-075-101-3,-7,-11, & -15	UHH,UHV	EA 1
226	248	PAOZZ	5975-00-902-5073	97499	204-075-164-41	...PANEL, BLANK U/O PN 205-075-101-19,-23, & -31	UHH,UHV	EA 1
226	249	PAOZZ	9905-00-845-0958	97499	204-075-164-1	...PLATE, IDENTIFICATION	UHH,UHV	EA 1
226	250	PBOZZ	5925-00-929-7271	96906	MS22073-1 1/2	...CIRCUIT BREAKER U/O PN 205-075-101-3,-7,-11,-15, CIRCUIT BREAKER 1.5 OR 2.0 AMP MAY BE USED FOR COURSE INDICATOR ON PANEL ASSEMBLY ON 205-075-101-15	UHH,UHV	EA 1
226	251	PAOZZ	5925-00-045-9095	76374	MP1501C	...CIRCUIT BREAKER U/O PN 205-075-101-3, & -7	UHH,UHV	EA 13
226	251	PAOZZ	5925-00-912-8343	96906	MS22073-1	...CIRCUIT BREAKER U/O PN 205-075-101-9,-13,-17,-21,-25, & -29	UHH,UHV	EA 1
226	251	PAOZZ	5925-00-912-8343	96906	MS22073-1	...CIRCUIT BREAKER U/O PN 205-075-101-15, & -27 P MAY BE USED FOR PN 205-075-101-15	UHH,UHV	EA 14
226	251	PAOZZ	5925-00-912-8343	96906	MS22073-1	...CIRCUIT BREAKER U/O PN 205-075-101-11,-19, & -23	UHH,UHV	EA 13
226	251	PAOZZ	5925-00-912-8343	96906	MS22073-1	...CIRCUIT BREAKER U/O PN 205-075-101-31	UHH,UHV	EA 12
226	251A	PAOZZ	5925-00-937-6669	96906	MS22073-10	...CIRCUIT BREAKER U/O PN 205-075-101-27	UHH,UHV	EA 1
226	251B	PAOZZ	5925-00-914-3505	96906	MS22073-2	...CIRCUIT BREAKER U/O PN 205-075-101-15,-19,-23,-27, & -31	UHH,UHV	EA 1
226	252	PAOZZ	3605-00-990-6444	96906	MS35207-261	...SCREW, MACHINE U/O PN 205-075-101-9,-13,-17,-21, & -25	UHH,UHV	EA 3
226	253	PAOZZ	5310-00-907-1474	96906	MS21042L3	...NUT, SELF-LOCKING, EXTENDED WASHER, HEXAGON U/O PN 205-075-101-9,-13,-17,-21, & -25	UHH,UHV	EA 3
226	254	PAOZZ	5310-00-167-0753	88044	AN980PD10L	...WASHER, FLAT U/O PN 205-075-101-9,-13,-17,-21, & -25	UHH,UHV	EA 5
226	255	PAOZZ	5935-00-660-7008	74545	5256	...CONNECTOR, RECEPTACL U/O PN 205-075-101-9,-13,-17,-21, & -25	UHH,UHV	EA 2
226	256	PAOZZ	1680-00-761-2829	97499	204-075-163-1	...PANEL ASSY	UHH,UHV	EA 1
226	259	PAOZZ	5305-00-889-3000	96906	MS35206-230	SCREW, MACHINE	UHH,UHV	EA 7
226	260	PAOZZ	6210-00-729-9396	72914	A5395C1	LIGHT, PANEL INDICATOR	UHH,UHV	EA 1
226	261	PAOZZ	5930-00-504-6223	96906	MS25089-4C	...SWITCH, PUSH	UHH,UHV	EA 1
226	265	PBOZZ	5305-00-984-7341	96906	MS35191-273	...SCREW, MACHINE	UHH,UHV	EA 2