

TECHNICAL MANUAL

NO. 55-1520-210-23-1

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, D.C., 30 September 1987

**AVIATION UNIT AND INTERMEDIATE
MAINTENANCE INSTRUCTIONS
ARMY MODEL UH-1H/V/EH-1H/X HELICOPTERS**

REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can improve this manual. If you find any mistakes or if you know of a way to improve these procedures, please let us know. Mail your letter or DA Form 2028 (Recommended Changes to Publications and Blank Forms) located in the back of this manual, directly to: Commander, U.S. Army Aviation and Missile Command, ATTN: AMSAM-MMC-MA-NP, Redstone Arsenal, AL 35898-5320. A reply will be furnished to you. You may also provide DA Form 2028 information to AMCOM via e-mail, or fax, or the World Wide Web. Our fax number is: DSN788-6546 or Commercial 256-842-6546. Our e-mail address is 2028@redstone.army.mil. Instructions for sending an electronic 2028 may be found at the back of this manual immediately preceding the hard copy 2028. For the World Wide Web use: <http://amcom2028.redstone.army.mil>.

Distribution Statement A: Approved for public release; distribution is unlimited.

TABLE OF CONTENTS

| | | PAGE |
|------------|---|-------------|
| CHAPTER 1 | INTRODUCTION | |
| Section I. | Servicing | 1-1 |
| II. | Lubrication | 1-50 |
| III. | Handling, Jacking, Mooring, Hoisting, and Sling Loading | 1-54 |
| IV. | Inspection Requirements | 1-66 |
| V. | Overhaul and Retirement Schedule | 1-110 |
| VI. | Flight Safety Critical Aircraft Parts | 1-115 |
| CHAPTER 2 | AIRFRAME | |
| Section I. | Fuselage | 2-1 |
| II. | Tailboom | 2-193 |
| CHAPTER 3 | ALIGHTING GEAR | |
| Section I. | Landing Gear | 3-1 |
| II. | Skids/Struts | 3-30 |
| III. | Floats | 3-30 |
| IV. | Skis | 3-30 |
| V. | Brakes | 3-30 |
| CHAPTER 4 | POWER PLANT | |
| Section I. | Power Plant | 4-1 |
| II. | Cooling System | 4-13 |
| III. | Air Induction System | 4-13 |
| IV. | Exhaust System | 4-42.7 |
| V. | Oil System | 4-44 |
| VI. | Ignition System | 4-61 |
| VII. | Power Controls | 4-61 |
| VIII. | Quick Change Assembly (AVIM) | 4-86 |