

(1) ILLUSTRATION		(2)	(3)	(4)	(5)	(6)	(7)	(8)
(A) FIG NO.	(B) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	FSCM	PART NUMBER	DESCRIPTION	USABLE ON CODE	QTY INC IN UNIT
290D	39	XDOZZ		96906	MS21122-17	.CLAMP, LOOP .....	UHV	EA 1
290D	40	PAOZZ	5305-00-059-3666	96906	MS51958-70	.SCREW, MACHINE .....	UHV	EA 2
290D	41	PAOZZ	5305-00-059-3661	96906	MS51958-65	.SCREW, MACHINE .....	UHV	EA 10
290D	42	PAOZZ	5340-00-205-6302	96906	MS21918DGS	.CLAMP, LOOP .....	UHV	EA 2
290D	43	PAOZZ	5340-00-052-9552	96906	MS21919DGS	.CLAMP, LOOP .....	UHV	EA 4
290D	44	PAOZZ	5340-00-598-8251	88044	AN743-12	.BRACKET, ANGLE .....	UHV	EA 3
290D	45	PAOZZ	5385-01-358-1789	80205	NAS43DD3-34	.SPACER, SLEEVE .....	UHV	EA 1
290D	46	PAOZZ	5999-00-901-3229	96906	MS24254-20P	.CONTACT .....	UHV	EA 4
290D	47	PAOZZ	5999-00-812-2082	96906	MS24255-20S	.CONTACT, ELECTRICAL .....	UHV	EA 4
290D	48	MOOZZ		96906	MS18029-1S4	.COVER, TERMINAL .....	UHV	EA 1
290D	49	AOOOO		19544	1580-UH1-914	.TERMINAL BOARD .....	UHV	EA 1
290D	50	PAFZZ	5961-01-037-0111	81349	JAN1N647-1	.SEMICONDUCTOR, DEVICE .....	UHV	EA 1
290D	51	PAFZZ	5970-00-431-3695	96906	MS3373-B1	.INSULATOR, PLATE .....	UHV	EA 1
290D	52	PAOZZ	5310-00-807-1472	96906	MS21042L06	.NUT, SELF-LOCKING, EX .....	UHV	EA 1
290D	53	PAOZZ	5310-00-722-5998	96906	MS15795-805	.WASHER, FLAT .....	UHV	EA 1
290D	54	PAOZZ	5940-00-204-8966	96906	MS25036-102	.TERMINAL, LUG .....	UHV	EA 1
290D	55	PAOZZ	5940-00-577-3807	96906	MS25036-145	.TERMINAL, LUG .....	UHV	EA 2
290D	56	PAOZZ	5310-00-807-1472	96906	MS21042L06	.NUT, SELF-LOCKING, EX .....	UHV	EA 1
290D	57	PAOZZ	5310-00-595-8211	96906	MS15795-803	.WASHER, FLAT .....	UHV	EA 2
290D	58	PAOZZ	5305-00-054-5849	96906	MS51957-15	.SCREW, MACHINE .....	UHV	EA 2
290D	59	PAFZZ		96906	MS27212-1-4	.TERMINAL BOARD .....	UHV	EA 1
290D	60	PBOZZ	5385-01-180-3921	81996	1580-UH1-887	.SPACER INSTRUMENT .....	UHV	EA 1
290D	61	PAOZZ	5365-01-179-9741	81996	1580-UH1-886	.SPACER INSTRUMENT .....	UHV	EA 1

PAGES 1236.1 THROUGH 1239 HAVE BEEN DELETED TO INCLUDE FIGURES 290E, 290F AND 291