

(1) ILLUSTRATION		(2)	(3)	(4)	(5)	(6) DESCRIPTION	(7)	(8)
(A) FIG NO.	(B) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	FSCM	PART NUMBER	USABLE ON CODE	U/M	QTY INC IN UNIT
226	102	MOOZZ	5970-00-195-9548	97499	130-005-6-4	INSULATION SLEEVING	UHH,UHV	EA 1
226	103	PAOZZ	5365-00-598-5282	96906	MS3420-4	BUSHING, RUBBER U/O PN 205-075-420-1	UHH,UHV	EA 1
226	104	PAOZZ	6145-00-578-6602	81349	MS0862-18-9	WIRE, ELECTRICAL	UHH,UHV	FT v
226	105	PBOZZ	6145-00-851-8505	96906	MS25190B20	WIRE, ELECTRICAL	UHH,UHV	FT v
226	106	PAOZZ	5305-00-957-7817	96906	MS24693S26	SCREW, MACHINE	UHH,UHV	EA 6
226	107	PBOZZ	6220-00-283-9337	88044	AN3033-9	LIGHT, NAVIGATION	UHH,UHV	EA 2
226	108	PAOZZ	5305-00-957-7819	96906	MS24693S30	SCREW, MACHINE	UHH,UHV	EA 1
226	109	PAOZZ	5330-00-260-8156	88044	AN889-1	GASKET	UHH,UHV	EA 1
226	110	PAOZZ	6220-00-151-7536	88044	AN3042-1	LENS, LIGHT	UHH,UHV	EA 1
226	111	PAOZZ	6220-00-497-2213	88044	AN3042-2	LENS, LIGHT	UHH,UHV	EA 1
226	112	PAOZZ	6240-00-681-8366	96906	MS25309-7512	LAMP, INCANDESCENT	UHH,UHV	EA 1
226	113	PAOZZ	5305-00-984-4988	96906	MS36206-228	SCREW, MACHINE	UHH,UHV	EA 32
226	114	PAOZZ	5310-00-187-2398	88044	AN960PDBL	WASHER, FLAT	UHH,UHV	EA 44
226	114A	PAOOO	6220-00-283-9334	88044	AN3177-9	LIGHT, NAVIGATION	UHH,UHV	EA 2
226	115	PAOZZ	5305-00-957-7819	96906	MS24693S30	SCREW, MACHINE	UHH,UHV	EA 1
226	116	PAOZZ	5330-00-292-0432	88044	AN899-1	GASKET	UHH,UHV	EA 1
226	117	PAOZZ	5330-00-813-0848	88044	AN904-1	GASKET	UHH,UHV	EA 1
226	118	PAOZZ	6220-00-432-4246	96906	MS25216-2	LENS, LIGHT	UHH,UHV	EA 1
226	119	PAOZZ	6240-00-155-7848	96906	MS15570-303	LAW, INCANDESCENT	UHH,UHV	EA 1
226	120	PAOZZ	6240-00-155-7924	96906	MS25235-311	LAW, INCANDESCENT	UHH,UHV	EA 1
226	121	PAOZZ	5330-00-700-4478	97499	204-075-151-1	GASKET	UHH,UHV	EA 2
226	124	PAOOO	6220-00-299-7136	96906	MS25358-1	LIGHT, DOME	UHH,UHV	EA 1
226	124A	PAOZZ	6220-00-283-9732	96906	MS25358-4	LENS, LIGHT	UHH,UHV	EA 1
226	125	PAOZZ	6240-00-155-7784	96906	MS35478-307	LAMP, INCANDESCENT	UHH,UHV	EA 3
226	126	PAOZZ	8240-00-155-7932	96906	MS25235R311	LAMP, INCANDESCENT	UHH,UHV	EA 3
226	129	XDOFF	1880-00-249-3330	97499	205-075-129-1	SUPPORT, ASSY, LIGHT	UHH,UHV	EA 1
226	130	XDFZZ	5310-00-275-4317	88044	AN362C832	NUT, SELF-LOCKING PLATE	UHH,UHV	EA 4
226	133	PBOOO	1560-00-781-9080	97499	205-075-331-3	SUPPORT, DOME LIGHT	UHH,UHV	EA 1
226	134	PAOZZ	5325-00-174-2923	88044	AN227-8	STUD, SNAP FASTENER	UHH,UHV	EA 4
226	135	PAOOO	1560-00-014-9524	97499	205-075-202-1	CONTROL PANEL ASSEMBLY -AFT DOME LIGHT SEE FIG.254 FOR BREAKDOWN	UHH,UHV	EA 1
226	135A	XCFZZ		97499	205-075-141-1	CONSOLE INSTL ELECTRICAL OVERHEAD U/O PN 205-075-006-1 SEE FIG.245 FOR BREAKDOWN	UHH,UHV	EA 1
226	135A	XCFZZ		97499	205-075-143-1	CONSOLE INSTL ELECTRICAL OVERHEAD U/O PN 205-075-008-1 SEE FIG.246 FOR BREAKDOWN	UHH,UHV	EA 1
226	135A	XCFZZ		97499	205-075-143-7	CONSOLE INSTL ELECTRICAL OVERHEAD U/O PN 205-075-008-3 SEE FIG.246 FOR BREAKDOWN	UHH,UHV	EA 1
226	135A	XCFZZ		97499	205-075-143-11	CONSOLE INSTL ELECTRICAL OVERHEAD U/O PN 206-075-008-5 SEE FIG.246 FOR BREAKDOWN	UHH,UHV	EA 1
226	135A	XCFZZ		97499	205-075-111-1	CONSOLE INSTL ELECTRICAL OVERHEAD U/O PN 206-075-013-1 & -3 SEE FIG.246 FOR BREAKDOWN	UHH,UHV	EA 1
226	135A	XCFZZ		97499	205-075-111-7	CONSOLE INSTL ELECTRICAL OVERHEAD U/O PN 205-075-018-1 SEE FIG.246 FOR BREAKDOWN	UHH,UHV	EA 1
226	135A	XCFZZ		97499	206-075-111-17	CONSOLE INSTL ELECTRICAL OVERHEAD U/O PN 205-075-018-3 SEE FIG.246 FOR BREAKDOWN	UHH,UHX	EA 1
226	135A	XCFZZ		97499	205-075-111-13	CONSOLE INSTL ELECTRICAL OVERHEAD U/O PN 205-075-032-1 SEE FIG.246 FOR BREAKDOWN	UHH,UHV	EA 1