

(1) ILLUSTRATION		(2)	(3)	(4)	(5)	(6) DESCRIPTION	(7)	(8)
(A) FIG NO.	(B) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	FSCM	PART NUMBER	USABLE ON CODE	U/M	QTY INC IN UNIT
276		XCFZZ		97499	205-075-003-3	ELECTRICAL INSTL PYLON USBL EFF 62-2108 THRU 64-13901 SEE FIG.128 FOR NHA UHH,UHV	EA	1
276		XCFZZ		97499	205-075-003-5	ELECTRICAL INSTL PYLON USBL EFF 65-9565 & SUBSEQUENT SEE FIG.128 FOR NHA UHH,UHV	EA	1
276	1	PAOZZ	5310-00-807-1474	96906	MS21042L3	NUT, SELF-LOCKING, EXTENDED WASHER, HEXAGON UHH,UHV	EA	4
276	2	PAOZZ	5310-00-167-0753	88044	AN960PD10L	WASHER, FLAT UHH,UHV	EA	3
276	3	PAOZZ	5305-00-989-7434	96906	MS35207-263	SCREW, MACHINE UHH,UHV	EA	4
276	4	PAOZZ	5340-00-533-3510	81996	EAB700-2	CLAMP, LOOP UHH,UHV	EA	2
276	4A	PAOZZ	5365-00-862-3088	80205	NAS430D3-32	SPACER, SLEEVE UHH,UHV	EA	1
276	4B	PAOZZ	5340-00-533-3512	81996	EAB700-5	CLAMP, LOOP UHH,UHV	EA	2
276	5	AOOOZ	1560-00-978-2173	97499	205-075-401-1	CABLE ASSEMBLY U/O PN 205-075-003-3 UHH,UHV	EA	1
276	5	AOOOZ	6150-00-924-0447	97499	205-075-433-9	CABLE ASSEMBLY U/O PN 205-075-003-5 UHH,UHV	EA	1
276	5A	PAOZZ	5935-00-543-0207	96906	MS3456W1233S	CONNECTOR, PLUG, ELEC XMSN OIL PRESS UHH,UHV	EA	2
276	6	PAOZZ	5935-00-240-0173	96906	MS3057-4A	CLAMP, CABLE, ELEC U/O PN 205-075-401-1 UHH,UHV	EA	1
276	7	PAOZZ	5935-00-988-4350	96906	MS3126E14-19P	CONNECTOR, PLUG, ELEC UHH,UHV	EA	1
276	8	PAOZZ	5340-00-984-2123	77820	10-101033-11	PLUG, PROTECTIVE, DUST MOISTURE SEAL U/O PN 205-075-401-1 UHH,UHV	EA	1
276	9	PAOZZ	5935-00-341-1258	96906	MS3456L1233S	CONNECTOR, PLUG, ELEC XMSN OIL TEMP BULB UHH,UHV	EA	1
276	9A	PAOZZ	5940-00-613-0698	96906	MS25036-101	TERMINAL, LUG U/O PN 205-075-401-1 UHH,UHV	EA	1
276	9A	PAOZZ	5940-00-204-8986	96906	MS25036-102	TERMINAL, LUG U/O PN 205-075-433-9 UHH,UHV	EA	2
276	9B	PAOZZ	5940-00-143-4771	96906	MS25036-103	TERMINAL, LUG U/O PN 205-075-433-9 UHH,UHV	EA	3
276	9B	PAOZZ	5940-00-143-4771	96906	MS25036-103	TERMINAL, LUG UHH,UHV	EA	1
276	9C	XDOZZ		97499	85T4-7-2	INSULATION TUBE U/O PN 205-075-401-1 UHH,UHV	EA	9
276	10	PBOZZ	6145-00-851-8505	96906	MS25190B20	WIRE, ELECTRICAL UHH,UHV	EA	V
276	10A	PBOZZ	5935-00-813-4716	96906	MS3108R10SL3S	CONNECTOR, PLUG, ELEC XMSN OIL PRESS XMTR UHH,UHV	EA	1
276	11	PAOZZ	5975-00-553-7151	96906	MS25171-2S	CABLE NIPPLE UHH,UHV	EA	1
276	12	PAOZZ	5310-00-807-1475	96906	MS21042L4	NUT, SELF-LOCKING, EXTENDED WASHER, HEXAGON UHH,UHV	EA	4
276	13	PAOZZ	5310-00-141-1795	88044	AN960-416	WASHER, FLAT UHH,UHV	EA	1
276	14	PAOZZ	6620-00-585-1503	81349	MILG26611	GENERATOR, TACHOMETER UHH,UHV	EA	1
276	14A	PAOZZ	5330-00-023-7623	96906	MS9134-01	GASKET UHH,UHV	EA	1
276	16	PAOZZ	5930-00-179-4546	97499	204-040-376-3	SWITCH, PRESSURE UHH,UHV	EA	1
276	16	PAOZZ	1560-00-716-8554	97499	100-016-1	PLUG, VENTILATION UHH,UHV	EA	1
276	17	PAOZZ	5330-00-531-2070	80205	NAS617-4	PACKING, PREFORMED UHH,UHV	EA	2
276	18	PAOZZ	6620-01-346-9340	58880	418-44044	TRANSMITTER, PRESSURE UHH,UHV	EA	1
276	19	PAOZZ	5330-00-835-8974	96906	MS29561-119	PACKING, PREFORMED UHH,UHV	EA	1
276	20	PAOZZ	5310-00-807-1477	96906	MS21042L6	NUT, SELF-LOCKING, EX WASHER, HEXAGON UHH,UHV	EA	6
276	21	PAOZZ	5310-00-167-0821	88044	AN960-616	WASHER, FLAT UHH,UHV	EA	6
276	22	PAODD	6115-00-901-1818	07878	GEU5A	GENERATOR, DIRECT CURRENT UHH,UHV	EA	1
276	22	PAODD	6115-00-725-1790	31435	30010-000	GENERATOR, DIRECT CURRENT SEE FIG.277 FOR BREAKDOWN UHH,UHV	EA	1
276	22	PAODD	6115-00-942-2094	82398	30B37-37	GENERATOR, DIRECT CURRENT SEE FIG.278 FOR BREAKDOWN UHH,UHV	EA	1
276	23	PCOZZ	5330-00-023-7626	96906	MS9136-01	GASKET UHH,UHV	EA	1
276	24	PAODD	6115-00-086-7607	97499	205-075-084-1	GENERATOR, ALTERNATI UHH,UHV	EA	1