

(1) ILLUSTRATION		(2)	(3)	(4)	(5)	(6)	(7)	(8)
(A) FIG. NO.	(B) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	FSCM	PART NUMBER	DESCRIPTION USABLE ON CODE	U/M	QTY INC IN UNIT
150		AOODD		97499	205-040-001-7	TRANSMISSION AND ASSEMBLY USBL EFF 62-2106 THRU 62-12372 SEE FIG. 128 FOR NHA. UHH, UHV	EA	1
150		AOODD		97499	205-040-001-13	TRANSMISSION AND MAST ASSEMBLY USBL EFF 63-8739 & SUBSEQUENT SEE FIG. 128 FOR NHA. UHH, UHV	EA	1
150	1	PAOZZ	5310-00-807-1476	96906	MS21042L5	NUT, SELF-LOCKING, EX WASHER, HEXAGON UHH, UHV	EA	10
150	2	PAOZZ	5310-00-825-4306	80205	NAS1197-516	WASHER, FLAT UHH, UHV	EA	10
150	3	PAOZZ	5310-00-167-0836	88044	AN960-516L	WASHER, FLAT UHH, UHV	EA	10
150	4	PAOOD	1615-00-255-2896	97499	204-040-366-15	MAST ASSEMBLY, TRANSMISSION UHH, UHV	EA	1
150	5	XAOOD		97499	204-011-450-7	MAST ASSEMBLY UHH, UHV	EA	1
150	6	PAFZZ	9905-00-060-2034	97499	100-024-1	PLATE, IDENTIFICATION UHH, UHV	EA	1
150	7	PAOZZ	5340-00-290-7229	99017	53	CAP, PROTECTIVE, D UHH, UHV	EA	1
150	9	PADZZ	3110-00-069-7207	97499	204-040-309-1	NUT UHH, UHV	EA	1
150	10	PADZZ	5315-00-234-1856	96906	MS24665-155	PIN, COTTER UHH, UHV	EA	2
150	11	PADDZ	3110-00-765-2383	97499	204-040-270-5	RING, BEARING, INNER UHH, UHV	EA	1
150	12	PADZZ	5306-00-145-6971	88044	AN503-8-6	SCREW, MACHINE UHH, UHV	EA	2
150	13	PADZZ	1615-00-071-8760	97499	205-040-236-1	LOCKWASHER, TRANSMISSION UHH, UHV	EA	1
150	14	PADZZ	5310-01-099-8545	97499	204-040-115-3	NUT, SELF-LOCKING, SP UHH, UHV	EA	1
150	15	PADZZ	5305-00-957-7811	96906	MS24693S272	SCREW, MACHINE UHH, UHV	EA	4
150	16	PADDD	3130-00-765-2389	97499	204-040-307-1	LINER, BEARING HOUSI UHH, UHV	EA	1
150	17	PADZZ	5340-00-290-4476	96906	MS21206F1-10	INSERT, SCREW THR UHH, UHV	EA	1
150	18	PADDD	3110-01-094-4412	97499	212-040-136-1	BEARING, BALL, ANNULA UHH, UHV	EA	1
150	19	PADZZ	5365-00-505-2338	97499	120-006C213-198	SHIM UHH, UHV	EA	1
150	20	PBFZZ	5305-00-889-2997	96906	MS35206-215	SCREW, MACHINE UHH, UHV	EA	2
150	21	PAFZZ	3110-00-829-6843	97499	204-040-347-1	PLATE, TRANSMISSION UHH, UHV	EA	1
150	22	PAFZZ	5330-00-875-7988	97499	204-040-244-1	SEAL, PLAIN UHH, UHV	EA	1
150	23	PAOZZ	5305-00-150-9213	88044	AN502-10-6	SCREW, MACHINE UHH, UHV	EA	1
150	24	PAOZZ	4730-00-698-4030	88044	AN929-4S	CAP, TUBE UHH, UHV	EA	1
150	25	PAOZZ	5330-00-580-5937	96906	MS29561-008	PACKING, PREFORMED UHH, UHV	EA	1
150	26	PAOZZ	1615-00-215-4301	97499	204-040-761-1	JET, OIL SPRAY ASSEM UHH, UHV	EA	1
150	27	PADZZ	9905-00-118-5663	97499	100-037-1M	PLATE, IDENTIFICATION UHH, UHV	EA	1
150	28	PADDD	1615-00-070-6821	97499	204-040-349-9	PLATE ASSEMBLY UHH, UHV	EA	1
150	29	PBDZZ	5340-00-597-3302	96906	MS124695	INSERT, SCREW THREAD UHH, UHV	EA	5
150	30	PBDZZ	5365-00-735-0196	83324	RL33SB9	RING, LOCK, SERRATED UHH, UHV	EA	8
150	31	PADZZ	5340-00-286-2465	83324	RAD207SB9	INSERT, SCREW THREAD UHH, UHV	EA	8
150	32	PADZZ	5340-00-826-2055	99017	EC48	CAP, PROTECTIVE, DUST U/O PN 204- 00-366-11 UHH, UHV	EA	1
150	32	PADZZ	5340-00-223-7118	99017	SC3-1-2	CAP, PROTECTIVE, DUST U/O PN 204- 040-366-11 UHH, UHV	EA	1
150	32A	PADZZ	1615-01-106-9085	97499	209-010-090-1	PLUG ASSEMBLY, MAST NOT USED WHEN MAST PN 204-040-366-15 IS INSTALLED USE-AFT-CMPL-W MWO 55- 1500-219-30-9 UHH, UHV	EA	1
150	32B	PAOZZ	5330-00-045-4559	96906	MS9241-233	PACKING, PREFORMED UHH, UHV	EA	2
150	33	PAOZZ	5310-00-807-1474	96906	MS21042L3	NUT, SELF-LOCKING, EX WASHER, HEXAGON U/O PN 204-040-009-33 & PN 205-040-001-13 UHH, UHV	EA	1
150	34	PAOZZ	5310-00-167-0753	88044	AN960PD10L	WASHER, FLAT U/O PN 204-040-009-33 & PN 205-040-001-13 UHH, UHV	EA	1
150	35	PAOZZ	5305-00-989-7434	96906	MS35207-263	SCREW, MACHINE U/O PN 204-040-009- 33, -49 & PN 205-040-001-13 UHH, UHV	EA	1
150	36	PAOZZ	5340-00-151-5997	96906	MS21122-4	CLAMP, LOOP U/O PN 204-040-009-33 & PN 205-040-001-13 UHH, UHV	EA	1
150	37	PAOZZ	5340-00-990-9301	81996	EAB700D7	CLAMP, LOOP U/O PN 204-040-009-33 & - 49 UHH, UHV	EA	1
150	38	XDOZZ	4720-00-727-2374	96906	MS87028E124	HOSE ASSEMBLY, NONME U/O PN 204- 040-009-33, -49 & PN 205-040-001-7 UHH, UHV	EA	1
150	39	AOODD		97499	205-040-001-17	TRANSMISSION ASSEMB SEE FIG. 153 FOR BREAKDOWN UHH, UHV	EA	1