

(1) ILLUSTRATION		(2)	(3)	(4)	(5)	(6)	(7)	(8)
(A) FIG NO.	(B) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	FSCM	PART NUMBER	DESCRIPTION	U/M	QTY INC IN UNIT
						USABLE ON CODE		
226	341	PAOZZ	5940-00-204-8966	96906	MS25036-102	..TERMINAL LUG U/O PN 205-075-413-1 & 205-075-418-1	UHH,UHV	EA 1
226	341	PAOZZ	5940-00-204-8966	96906	MS25036-102	..TERMINAL LUG U/O PN 205-075-433-3 & -11	UHH,UHV	EA 13
226	341	PAOZZ	5940-00-204-8966	96906	MS25036-102	..TERMINAL LUG U/O PN 205-075-901-1	UHH,UHV	EA 14
226	342	PAOZZ	5940-00-143-4771	96906	MS25036-103	..TERMINAL LUG U/O PN 205-075-413-1 & 205-075-418-1	UHH,UHV	EA 1
226	342	PAOZZ	5940-00-143-4771	96906	MS25036-103	..TERMINAL LUG U/O PN 205-075-433-3,-11 & 205-075-901-1	UHH,UHV	EA 6
226	344	PAOZZ	5940-00-557-1629	96906	MS25036-149	..TERMINAL LUG U/O PN 205-075-413-1, 205-075-418-1, 205-075-433-3 & -11	UHH,UHV	EA 1
226	345	PAOZZ	5940-01-079-1647	81349	M7928/5-3	..SPLICE, CONDUCTOR U/O PN 205-075-413-1 & 205-075-418-1	UHH,UHV	EA 1
226	345	PAOZZ	5940-01-079-1647	81349	M7928/5-3	..SPLICE, CONDUCTOR U/O PN 205-075-433-3,-11 & 205-075-901-1	UHH,UHV	EA 5
226	346	PAOZZ	5999-00-661-0416	96906	MS25274-2	..CAP, ELECTRICAL U/O PN 205-075-418-1 & 205-075-433-11	UHH,UHV	EA 1
226	347	PBOZZ	5935-00-721-3845	81349	M28748/6C00G1A	..CONNECTOR, RECEPTACLE	UHH,UHV	EA 1
226	348	MOOZZ		97499	130-005-6-4	..INSULATION SLEEVING	UHH,UHV	EA 1
226	349	MOOZZ		97499	85T4-10-2	..INSULATION SLEEVING U/O PN 205-075-413-1 & 205-075-418-1	UHH,UHV	EA 1
226	349	MOOZZ		97499	85T4-10-2	..INSULATION SLEEVING U/O PN 205-075-433-3 & -11	UHH,UHV	EA 21
226	349	MOOZZ		97499	85T4-10-2	..INSULATION SLEEVING U/O PN 205-075-901-1	UHH,UHV	EA 24
226	350	XDOZZ		97499	85T4-7-2	..INSULATION TUBE U/O PN 205-075-413-1 & 205-075-418-1	UHH,UHV	FT 1
226	350	XDOZZ		97499	85T4-7-2	..INSULATION TUBE U/O PN 205-075-433-3,-11 & 205-075-901-1	UHH,UHV	FT 3
226	351	PBOZZ	6145-00-578-6605	81349	M5086/2-16-9	..WIRE, ELECTRICAL	UHH,UHV	FT V
226	352	PBOZZ	5940-00-636-7098	96906	MS25189-102	..TERMINAL LUG	UHH,UHV	FT V
226	353	PBOZZ	6145-00-643-0651	81349	MILW16878TYPEB18	..WIRE, ELECTRICAL	UHH,UHV	FT V
226	354	PAOZZ	5940-00-683-4282	97499	30-010-1	..SPLICE, CONDUCTOR U/O PN 205-075-901-1	UHH,UHV	EA 2
226	355	PBOZZ	6145-00-819-0061	81349	MILW16878TYPEB20	..WIRE, ELECTRICAL	UHH,UHV	FT V
226	356	MOOZZ		97499	85T4-2-108	..INSULATION SLEEVING U/O PN 205-075-032-1	UHH,UHV	EA 1
226	357	MOOZZ		97499	85T4-1-106	..INSULATION SLEEVING U/O PN 205-075-032-1,-3,-13,-15, 205-075-036-1,-3,-7,-9 & -11	UHH,UHV	EA 1
226	358	MOOZZ		97499	85T4-2-116	..TUBE INSULATION U/O PN 205-075-032-1,-3,-13,-15, 205-075-036-1,-3,-7,-9, & -11	UHH,UHV	EA 1
226	359	MOOZZ		97499	85T4-4-8	..INSULATION TUBE U/O PN 205-075-032-1,-3,-13,-15, 205-075-036-1,-3,-7,-9 & -11	UHH,UHV	EA 1
226	359A	PAOZZ	5935-00-773-3052	31312	MRAC26SJTC8H8	..CONNECTOR BODY, PLUG	UHH,UHV	EA 1
226	360	PAOZZ	5908-00-515-8064	88044	AN4-7A	..BOLT, MACHINE U/O PN 205-075-036-1 & -11	UHH,UHV	EA 1
226	361	PAOFF	1680-00-105-9316	97499	204-075-705-9	..PANEL, FAULT-FUNCTION INDICATOR U/O PN 205-075-008-1,-3,-5, 205-075-013-1 & -3	UHH,UHV	EA 1
226	361	PAOFF	1680-00-285-7984	98182	249-100	..PANEL, FAULT-FUNCTION INDICATOR SEE FIG.238 FOR BREAKDOWN U/O PN 205-075-008-1,-3,-5, 205-075-013-1 & -3	UHH,UHV	EA 1
226	361	PAOFF	1680-00-105-9316	72914	90-0070-1	..PANEL, FAULT-FUNCTION INDICATOR SEE FIG.237 FOR BREAKDOWN U/O PN 205-075-008-1,-3,-5, 205-075-013-1 & -3	UHH,UHV	EA 1
226	361	PAOFF	1680-00-850-4381	97499	204-075-705-45	..PANEL, FAULT-FUNCTION CAUTION CONTROL SEE FIG.231 & 232 FOR BREAKDOWN INTRCH U/O 205-075-036-1,-3,-7,-9,-11,-15,-17, U/O 205-075-018-1,-3, 205-075-032-1,-3,-9,-13,-15	UHH,UHV	EA 1