

(1) ILLUSTRATION		(2)	(3)	(4)	(5)	(6) DESCRIPTION	(7)	(8)
(A) FIG NO.	(B) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	FSCM	PART NUMBER	USABLE ON CODE	U/M	QTY INC IN UNIT
226	183B	PAOZZ	1680-01-230-0529	81996	EGD-0942-3	..FILTER, INSTRUMENT, L USE AFTER NIGHT VISION GOGGLES ARE INSTALLED .....	UHH,UHV	EA 2
226	183B	PAOZZ	1680-01-129-5414	81996	6210-EG-002-8	..FILTER, INSTRUMENT, L USE AFTER NIGHT VISION GOGGLES ARE INSTALLED .....	UHH,UHV	EA 1
226	183B	PAOZZ	1680-01-129-5415	81996	6210-EG-002-9	..FILTER, INSTRUMENT, L USE AFTER NIGHT VISION GOGGLES ARE INSTALLED .....	UHH,UHV	EA 1
226	183C	PAOZZ	5975-00-984-6582	96906	MS3367-1-0	..STRAP, TIEDOWN U/O PN EGD-0942-3 .....	UHH,UHV	EA 2
226	184	PAOZZ	6240-00-155-8714	96906	MS25231-313	..LAMP, INCANDESCENT .....	UHH,UHV	EA 1
226	184A	PBOZZ	6220-00-500-3682	96906	MS17246-1	..MOUNTING BASE, LIGHT COCKPIT U/W MS17245-5A .....	UHH,UHV	EA 2
226	185	PAOZZ	5310-00-807-1472	96906	MS21042L06	..NUT, SELF-LOCKING, EXTENDED WASHER, HEXAGON .....	UHH,UHV	EA 2
226	186	PAOZZ	5310-00-188-7721	88044	AN960PD06	..WASHER, FLAT .....	UHH,UHV	EA 4
226	191	MOOZZ		94640	397-1	..COVER, TERMINAL BOARD .....	UHH,UHV	EA 2
226	195	MOOZZ		96906	MS27212-1-1	..TERMINAL BOARD .....	UHH,UHV	EA 2
226	196	XCFZZ		97499	204-075-177-15	..PANEL, INSTL CIRCUIT BREAKER, EXTERNAL STORES U/O PN 205-075-006-1 SEE FIG.248 FOR BREAKDOWN .....	UHH,UHV	EA 1
226	197	PAOZZ	5305-00-957-7817	96906	MS24693S26	..SCREW, MACHINE .....	UHH,UHV	EA 3
226	198	PBOOO	6220-00-283-9337	88044	AN3033-9	..LIGHT, NAVIGATION .....	UHH,UHV	EA 2
226	199	PAOZZ	5305-00-957-7819	96906	MS24693S30	..SCREW, MACHINE .....	UHH,UHV	EA 1
226	200	PAOZZ	5330-00-260-8156	88044	AN889-1	..GASKET .....	UHH,UHV	EA 1
226	201	PAOZZ	6220-00-151-7536	88044	AN3042-1	..LENS, LIGHT, NAVIGATIONAL LIGHT-RED .....	UHH,UHV	EA 1
226	202	PAOZZ	6220-00-497-2243	88044	AN3042-2	..LENS, LIGHT, NAVIATIONAL LIGHT-GREEN .....	UHH,UHV	EA 1
226	203	PAOZZ	6240-00-681-8366	96906	MS25309-7512	..LAMP, INCANDESCENT .....	UHH,UHV	EA 1
226	205A	PAOOO	6220-00-283-9334	88044	AN3177-9	..LIGHT, NAVIGATIONAL .....	UHH,UHV	EA 1
226	206	PAOZZ	5305-00-957-7819	96906	MS24693S30	..SCREW, MACHINE .....	UHH,UHV	EA 1
226	207	PAOZZ	5330-00-813-0648	88044	AN904-1	..GASKET .....	UHH,UHV	EA 1
226	208	PAOZZ	5330-00-292-0432	88044	AN896-1	..GASKET .....	UHH,UHV	EA 1
226	209	PAOZZ	6220-00-432-4244	96906	MS25216-1	..LENS, LIGHT NAVIGATIONAL .....	UHH,UHV	EA 1
226	210	PAOZZ	6240-00-155-7924	96906	MS25235-311	..LAMP, INCANDESCENT .....	UHH,UHV	EA 1
226	211	PAOZZ	6240-00-155-7848	96906	MS15570-303	..LAMP, INCANDESCENT .....	UHH,UHV	EA 1
226	212	PAOZZ	5330-00-700-4478	97499	204-075-151-1	..GASKET .....	UHH,UHV	EA 1
226	213	PAOZZ	5305-00-889-2999	96906	MS36206-217	..SCREW, MACHINE .....	UHH,UHV	EA 16
226	214	PAOZZ	5310-00-187-2397	88044	AN960PD4L	..WASHER, FLAT .....	UHV	EA 4
226	215	PAODD	6220-00-144-4687	91349	M81174-2-1A	..LIGHT, LANDING, AIRCRAFT INTRCH .....	UHH,UHV	EA 1
226	215A	PAOZZ	1680-01-230-0530	81996	EGD-0931-1	..FILTER, SEARCHLIGHT, NVG .....	UHH	EA 1
226	216	PAOZZ	6240-00-557-3065	96906	MS25241-4581	..LAMP, INCANDESCENT .....	UHH,UHV	EA 1
226	216A	PAOZZ	6240-00-690-1094	08806	4571	..LAMP, INCANDESCENT USE WITH PN EGD-0931-1 ONLY .....	UHH	EA 1
226	218	PAOZZ	5310-00-184-9002	88044	AN960PD8L	..WASHER, FLAT .....	UHH,UHV	EA V
226	219	PAOFF	6220-00-076-1989	72914	G8385-1	..LIGHT, LANDING, AIRCR SEE FIG.244 FOR BREAKDOWN .....	UHH,UHV	EA 1
226	219A	PAOZZ	6240-00-557-3065	96906	MS25241-4581	..LAMP, INCANDESCENT .....	UHH,UHV	EA 1
226	219B	PAOZZ	6240-00-690-1094	08806	4571	..LAMP, INCANDESCENT USE WITH PN EGD-0931-1 ONLY .....	UHV	EA 1
226	221	PAOZZ	5310-00-184-9001	88044	AN960PD416L	..WASHER, FLAT .....	UHH,UHX	EA 2
226	222	PAOZZ	5306-00-182-2017	88044	AN4H6A	..BOLT, MACHINE .....	UHH,UHV	EA 1
226	223	PAOZZ	6150-00-771-5731	97499	204-075-153-1	..BUS, CONDUCTOR .....	UHH,UHV	EA 1
226	224	XDOZZ		86928	5712-88-16	..WASHER, FLAT U/O PN 205-075-018-1 & -3 .....	UHH,UHV	EA V