

(1) ILLUSTRATION		(2)	(3)	(4)	(5)	(6) DESCRIPTION	(7)	(8)
(A) FIG NO.	(B) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	FSCM	PART NUMBER	USABLE ON CODE	U/M	QTY INC IN UNIT
226	135A	XCFZZ		97499	205-075-111-23	CONSOLE INSTL ELECTRICAL OVERHEAD U/O PN 205-075-032-3 SEE FIG.246 FOR BREAKDOWN UHH,UHV	EA	1
226	135A	XCFZZ		97499	205-075-111-33	CONSOLE INSTL ELECTRICAL OVERHEAD U/O PN 205-075-032-13 SEE FIG.246 FOR BREAKDOWN UHH,UHV	EA	1
226	135A	XCFZZ		97499	205-075-111-37	CONSOLE INSTL ELECTRICAL OVERHEAD U/O PN 205-075-032-9 SEE FIG.280 FOR BREAKDOWN UHH,UHV	EA	1
226	135A	XCFZZ		97499	205-075-111-41	CONSOLE INSTL ELECTRICAL OVERHEAD U/O PN 205-075-032-15 SEE FIG.246 FOR BREAKDOWN UHH,UHV	EA	1
226	135A	XCFZZ		97499	205-075-111-45	CONSOLE INSTL ELECTRICAL OVERHEAD U/O PN 205-075-036-1 SEE FIG.246 FOR BREAKDOWN UHH,UHV	EA	1
226	135A	XCFZZ		97499	205-075-111-51	CONSOLE INSTL ELECTRICAL OVERHEAD U/O PN 205-075-036-3 SEE FIG.246 FOR BREAKDOWN UHH,UHV	EA	1
226	135A	XCFZZ		97499	205-075-111-59	CONSOLE INSTL ELECTRICAL OVERHEAD U/O PN 205-075-036-7 SEE FIG.246 FOR BREAKDOWN UHH,UHV	EA	1
226	135A	XCFZZ		97499	205-075-156-1	CONSOLE INSTL ELECTRICAL OVERHEAD U/O PN 205-075-036-9 SEE FIG.246 FOR BREAKDOWN UHH,UHV	EA	1
226	135A	XCFZZ		97499	205-075-156-25	CONSOLE INSTL ELECTRICAL OVERHEAD U/O PN 205-075-036-11 SEE FIG.246 FOR BREAKDOWN UHH,UHV	EA	1
226	135A	XCOZZ		97499	205-075-156-45	CONSOLE INSTL ELECTRICAL OVERHEAD SEE FIG.246 FOR BREAKDOWN UHH,UHV	EA	1
226	136	PAOZZ	5305-00-984-4988	96906	MS35206-228	SCREW, MACHINE U/O PN 205-075-006-1, 205-075-008-1, -3, -5, 205-075-013-1, -3, 205-075-018-1, -3, 205-075-032-1, -3, -9, -13 & -15 UHH,UHV	EA	12
226	136	PAOZZ	5305-00-984-4988	96906	MS35206-228	SCREW, MACHINE U/O PN 205-075-036-1 & -3 UHH,UHV	EA	4
226	137	PAOZZ	5310-00-187-2398	88044	AN960PD6L	WASHER, FLAT U/O PN 205-075-006-1, 205-075-008-1, -3, -5, 205-075-013-1, -3, 205-075-018-1, -3, 205-075-032-1, -3, -9, -13 & -15 UHH,UHV	EA	12
226	137	PAOZZ	5310-00-187-2398	88044	AN960PD6L	WASHER, FLAT U/O PN 205-075-036-1, -3, -7 & -9 & -11 UHH,UHV	EA	4
226	138	PAOZZ	5310-00-807-1472	96906	MS21042L06	.NUT, SELF-LOCKING, EX EXTENDED WASHER, HEXAGON U/O PN 205-075-006-1, 205-075-008-1, -3, -5, 205-075-013-1, -3, 205-075-018-1, -3, 205-075-032-1, -3, -9, -13, & -15 UHH,UHV	EA	12
226	138	PAOZZ	5310-00-807-1472	96906	MS21042L06	.NUT, SELF-LOCKING, EX EXTENDED WASHER, HEXAGON U/O PN 205-075-036-1, -3, -7, -9, & -11 UHH,UHV	EA	4
226	139	PAOZZ	5935-00-241-0355	74545	7528	CONNECTOR, RECEPTACLE U/O PN 205-075-006-1, 205-075-008-1, -3, -5, 205-075-013-1, -3, 205-075-018-1, -3, 205-075-032-1, -3, -9, -13, & -15 UHH,UHV	EA	6
226	139	PAOZZ	5935-00-241-0355	74545	7528	CONNECTOR, RECEPTACLE U/O PN 205-075-036-1, -3, -7, -9 & -11 UHH,UHV	EA	2
226	140	MFOZZ	DELETED	96906	MS20253-2225	.PIN, STRAIGHT, HEA HEADLESS UHH,UHV	EA	1
226	141	XBOOZ	8240-00-759-9804	97499	204-075-144-9	.CONTAINER ASSEMB SPARE LAMP UHH,UHV	EA	1
226	142	PAOZZ	5325-00-174-5317	96906	MS35489-4	.GROMMET, NONMETALLIC UHH,UHV	EA	5
226	143	PAOZZ	5325-00-291-8386	96906	MS35489-11	.GROMMET, NONMETALLIC UHH,UHV	EA	2
226	144	PAOZZ	5325-00-281-1557	96906	MS35489-17	.GROMMET, NONMETALLIC UHH,UHV	EA	2
226	145	PAOZZ	5325-00-281-8204	72794	AW3 1-2T10	.STUD, TURNLOCK FA FASTENER UHH,UHV	EA	1
226	146	PAOZZ	5325-00-281-4989	72794	GH3-1-2	.EYELET, TURNLOCK FASTER UHH,UHV	EA	1
226	147	PAOZZ	8240-00-155-8714	96906	MS25231-313	.LAMP, INCANDESCENT UHH,UHV	EA	1
226	149	PAOZZ	8240-00-155-7832	96906	MS25235R311	.LAMP, INCANDESCENT UHH,UHV	EA	1
226	150	PAOZZ	8240-00-155-7836	96906	MS25237-327	.LAMP, INCANDESCENT UHH,UHV	EA	6
226	151	PAOZZ	8240-00-298-4742	96906	MS25069-1495	.LAMP, INCANDESCENT UHH,UHV	EA	1
226	152	AOOOZ	1560-00-868-8155	97499	205-075-431-3	.CABLE ASSY, WIND SHIELD WIPER-PILOTS U/O PN 205-075-013-1, -3, 205-075-018-1, 205-075-032-1, -3, -9, -13, -15, 205-075-036-1, -3, -7, -9, & -11 UHH,UHV	EA	1