

TECHNICAL MANUAL

NO. 55-1520-210-23P-2

HEADQUARTERS,  
DEPARTMENT OF THE ARMY,  
WASHINGTON, D.C., 27 February 1981

**AVIATION UNIT AND INTERMEDIATE MAINTENANCE  
REPAIR PARTS AND SPECIAL TOOLS LIST  
(INCLUDING DEPOT MAINTENANCE REPAIR PARTS  
AND SPECIAL TOOLS)  
FOR  
HELICOPTER, UTILITY - TACTICAL TRANSPORT  
UH-1B, UH-1C, UH-1H, UH-1M, EH-1H (BELL) AND UH-1V**

NSN 1520-00-713-9912 (UH-1B)  
1520-00-997-8862 (UH-1C)  
1520-00-087-7637 (UH-1H)  
1520-00-809-2631 (UH-1M)  
1520-00-368-8442 (EH-1H)  
1520-00-043-4949 (UH-1V)

Current as of 15 November 2004

**NOTE**

This manual is printed in three volumes as follows:  
TM 55-1520-210-23P-1, consisting of Table of Contents, Section I, and Section II (Functional Groups 02 thru 06).  
TM 55-1520-210-23P-2, consisting of Section II (Functional Groups 07 thru 14).  
TM 55-1520-210-23P-3, consisting of Section II (Functional Groups 16 thru 60), Section III, and Section IV.  
The Table of Contents, Section I, and IV are applicable to the -1, -2, and -3.

**REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS**

You can improve this manual. If you find any mistakes or if you know of a way to improve these procedures, please let us know. Mail your letter or DA Form 2028 (Recommended Changes to Publications and Blank Forms) located in the back of this manual, directly to: Commander, U.S. Army Aviation and Missile Command, ATTN: AMSAM-MMC-MA-NP, Redstone Arsenal, AL 35898-5320. A reply will be furnished to you. You may also provide DA Form 2028 information to AMCOM via e-mail, or fax, or the World Wide Web. Our fax number is: DSN 788-6546 or Commercial 256-842-6546. Our e-mail address is [2028@redstone.army.mil](mailto:2028@redstone.army.mil). Instructions for sending an electronic 2028 may be found at the back of this manual immediately preceding the hard copy 2028. For the World Wide Web use: <http://amcom2028.redstone.army.mil>.

**Distribution Statement A:** Approved for public release; distribution is unlimited.

**TABLE OF CONTENTS**

	LISTING PAGE	ILLUS/ FIGURE
Section I		
INTRODUCTION .....		
Deleted .....	9	1
Deleted .....	10	2
Exploded view of UH-1H Helicopter .....	11	3
Section II		
REPAIR PARTS LIST		
FUNCTIONAL GROUP 02 AIRFRAME		
Section assembly, forward .....	12	4