



## AIR MOBILITY

# Add a Little Lift




Want to save a lot of sweat and elbow grease when checking the Huey engine mount rod-end bearings during a phase inspection?



It's easy! You don't have to remove all the rods for a bench check of the bearings.

Using a sling and hoist, lift the engine just enough to take the load off the bearings.



Then, with a dial indicator, inspect the bearings for the radial and axial play limits given in Para 2-270b of TM 55-1520-210-23.