



## HELLHOLE CLEAN?

It's a capital idea to keep the hellhole free of dirt, safety wire and other debris, Huey mechs.

During a flair or hover dust is sucked up around the main drive shaft at the engine intake baffle.

The particle separator is not designed to screen this dirt, which lodges in the compressor. You know what that means—a dirty compressor, robbing your engine of power.

Keep the hellhole clean, man!

