

	LISTING PAGE	ILLUS/ FIGURE
Deleted	822	193
Deleted	826	194
Deleted	830	195
Deleted	834	196
Deleted	836	198
Deleted	840	199
Deleted	846	200
Hydraulic installation, forward inboard section	852	201
Hydraulic installation, pump section	856	202
Hydraulic installation, center section	860	203
Hydraulic installation, center section	864	203A
Valve assembly, irreversible flight control	864.4	204
Hydraulic installation, aft section	868	205
Hydraulic installation, aft section	872	206
Tank, hydraulic fluid	876	207
Servo cylinder, hydraulic	878	208
Servo cylinder, hydraulic	880	208A
Deleted	882	210
Hydraulic installation, armament	886	211
 FUNCTIONAL GROUP 08 INSTRUMENT SYSTEMS		
Panel and pedestal installation, instrument	890	212
Glare shield assembly	894	213
Panel assembly, instrument (left hand section)	896	216
Panel assembly, instrument (center section)	902	217
Panel assembly, instrument	906	218
Piping installation, pitot	912	222
Piping installation, instrument	914	223
Deleted	918	224
Deleted	918.2	224A
 FUNCTIONAL GROUP 09 ELECTRICAL SYSTEMS		
Deleted	920	225
Electrical installation, forward section	946	226
Deleted	976	226A
Deleted	976.2	226B
Electrical installation, rescue hoist and door gunners foot mike switch	978	227
Electrical installation, rescue hoist and discrete signal discriminator	982	228
Electrical installation, smoke generator	986	229
Deleted	988	230
Panel assembly, master caution	992	231
Panel assembly-word caution control	998	233
Panel assembly, master caution	1004	234
Deleted	1010	236
Panel, fault-function indicator	1014	237
Panel, fault-function indicator	1020	238
Box, RPM warning control	1024	240
Circuit, card assembly	1026	240A
Equipment installation, nose compartment electrical	1030	241
Equipment installation, nose compartment, electrical	1036	242