

(1) ILLUSTRATION		(2)	(3)	(4)	(5)	(6) DESCRIPTION	(7)	(8)
(A) FIG NO.	(B) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	FSCM	PART NUMBER	USABLE ON CODE	U/M	QTY INC IN UNIT
218	88	PAODD	6610-00-905-0210	99251	DSA274	INDICATOR, ATTITUDE UHH,UHV	EA	1
218	88	PADDD	6610-01-023-6073	35351	148700-03-01	INDICATOR, ATTITUDE UHH,UHV	EA	1
218	88	PADDD	6610-00-482-8498	99251	DSA274-4	INDICATOR, ATTITUDE UHH,UHV	EA	1
218	88	PAODD	6610-00-912-3613	10138	102550	INDICATOR, ATTITUDE INTRCH UHH,UHV	EA	1
218	68A	PAOZZ	1680-01-230-0525	81996	EGD-0928-3	.BEZEL UHH,UHV	EA	1
218	69	PAOZZ				DELETED		
218	69A	PAOZZ	5305-00-954-8154	96906	MS35215-61	SCREW, MACHINE UHH,UHV	EA	4
218	70	PBOZZ	5305-00-225-6214	96906	MS24693BB275	SCREW, MACHINE UHH,UHV	EA	4
218	71	PAOZZ				DELETED		
218	72	XBOFF				DELETED		
218	72	XBOFF				DELETED		
218	72	XBOFF				DELETED		
218	72	XDOFF		97499	204-070-475-45	PANEL ASSEMBLY U/O PN 205-070-120-3, -5, -7, -11, & -13 UHH,UHV	EA	1
218	72	XBOFF		97499	205-070-948-31	PANEL ASSEMBLY U/O PN 205-070-949-1 UHH,UHV	EA	1
218	72	XBOFF		97499	205-070-948-39	PANEL ASSEMBLY U/O PN 205-070-949-5 OBS AFT Cmpl W/MWO 55-1520-242-50-XX UHH,UHV	EA	1
218	72	XBOFF		97499	205-070-948-47	PANEL ASSEMBLY U/O PN 205-070-949-19 UHH,UHV	EA	1
218	72	XDOFF				DELETED		
218	72	XDOOO		20309	ES-7-221283	INSTR PANEL USED ON ES-J-221282 UHH,UHV	EA	1
218	73	MOOZZ		97499	204-070-749-1	.BRACKET, INSTRUMENT UHH,UHV	EA	1
218	74	PAOZZ	5310-00-728-7716	96906	MS21069L3	.NUT, SELF-LOCKING PLATE UHH,UHV	EA	1
218	75	PAOZZ	5305-00-458-0586	96906	MS35207-273	SCREW, MACHINE UHH,UHV	EA	2
218	76	PAFZZ	5365-00-727-1891	80205	NAS43DD3-128	SPACER, SLEEVE UHH,UHV	EA	2
218	77	PAFZZ	5340-00-151-5998	96906	MS21122-8	CLAMP, LOOP UHH,UHV	EA	2
218	78	PAFZZ	5310-00-167-0818	88044	AN960-10	.WASHER, FLAT UHH,UHV	EA	2
218	79	XCFZZ				DELETED		
218	80	PAOZZ				DELETED		
218	81	PAOZZ				DELETED		
218	82	PAOZZ				DELETED		
218	83	XDOZZ				DELETED		