


Have you Huey and Cobra mechs ever wondered why the T1 temperature sensor element is inclosed in the housing assembly when you unpack a T53 fuel control?

It's because the element will flop around and get broken during shipment if it's not secured to the shipping plate!

That's why you want to ship a removed fuel control back to depot with the element in its housing—bolted down.



Fact is, depot is running out of element housings. Send 'em back every time.