




Huey Blade Grip Safety . . .

Nearest Hole's OK



There's no need to retorque the main rotor blade retaining nut just because the head of the safety screw (item 1, fig 169, TM 55-1520-210-23P (Mar 77) doesn't point to the exact center of the mast.

Just use the screw hole closest to the rotor mast centerline . . . saves elbow grease!

