

(1) ILLUSTRATION		(2)	(3)	(4)	(5)	(6) DESCRIPTION	(7)	(8)
(A) FIG NO.	(B) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	FSCM	PART NUMBER	USABLE ON CODE	U/M	QTY INC IN UNIT
GROUP 11 FLIGHT CONTROL SYSTEM								
346		XCFZZ		97499		CONTROL INSTL ANTI-TORQUE USBL EFF 62-2106 THRU 62-12372 SEE FIG.7 FOR NHA SEE FIG.345 FOR BALANCE OF BREAKDOWN UHH,UHV	EA	1
346		XCFZZ		97499	205-001-002-5	CONTROL INSTL ANTI-TORQUE USBL EFF 63-8739 THRU 63-13002 SEE FIG.7 FOR NHA SEE FIG.345 FOR BALANCE OF BREAKDOWN UHH,UHV	EA	1
346		XCFZZ		97499	205-001-002-7	CONTROL INSTL ANTI-TORQUE USBL EFF 64-1342 THRU 64-13901 SEE FIG.7 FOR NHA SEE FIG.345 FOR BALANCE OF BREAKDOWN UHH,UHV	EA	1
346		XCFZZ		97499	205-001-002-11	CONTROL INSTL ANTI-TORQUE USBL EFF 65-8585 THRU 65-12895 SEE FIG.7 FOR NHA SEE FIG.345 FOR BALANCE OF BREAKDOWN UHH,UHV	EA	1
346		XCFZZ		97499	205-001-002-13	CONTROL INSTL ANTI-TORQUE USBL EFF 66-746 THRU 66-17144 & 66-8574 THRU 66-8577 SEE FIG.7 FOR NHA SEE FIG.345 FOR BALANCE OF BREAKDOWN UHH,UHV	EA	1
346		XCFZZ		97499	205-001-002-15	CONTROL INSTL ANTI-TORQUE USBL EFF 67-17145 THRU 67-17777 SEE FIG.7 FOR NHA SEE FIG.345 FOR BALANCE OF BREAKDOWN UHH,UHV	EA	1
346		XCFZZ		97499	205-001-002-19	CONTROL INSTL ANTI-TORQUE USBL EFF 67-17778 & SUBSEQUENT SEE FIG.7 FOR NHA SEE FIG.345 FOR BALANCE OF BREAKDOWN UHH,UHV	EA	1
346	1	PAOZZ	5306-00-182-1958	88044	AN4H10A	.BOLT, MACHINE UHH,UHV	EA	1
346	2	PAOZZ	5306-00-182-1984	88044	AN4H16A	.BOLT, MACHINE UHH,UHV	EA	3
346	3	PAOZZ	5310-00-187-2354	88044	AN960PD416	.WASHER, FLAT UHH,UHV	EA	26
346	3A	PAOZZ	5310-00-184-9001	88044	AN960PD416L	.WASHER, FLAT UHH,UHV	EA	2
346	4	PAOZZ	5310-00-877-5796	96906	MS21044N4	.NUT, SELF-LOCKING, HEXAGON UHH,UHV	EA	4
346	5	PAOFF	1560-00-824-5108	97499	204-001-102-1	SUPPORT ASSY, BELL CRANK U/O PN 205-001-002-3,-5,-7,-11 & -13 SEE FIG.67 & 70 FOR SUPPORT ASSY USBL EFF 67-17145 & SUBSEQUENT UHH,UHV	EA	1
346	6	PAFZZ	3120-00-625-0051	97499	22-007-19-19-18	.BUSHING, SLEEVE UHH,UHV	EA	2
346	7	MFOZZ	DELETED	97499	205-001-104-1	.SHIM U/O PN 205-001-002-3,-5,-7,-11,-13 UHH,UHV	EA	1
346	8	PAOZZ	5306-00-151-0332	88044	AN174H20	.BOLT, MACHINE UHH,UHV	EA	1
346	9	PAOZZ	5310-00-167-1285	88044	AN310-4	.NUT, PLAIN UHH,UHV	EA	1
346	9A	PAOZZ	5310-00-961-8390	96906	MS17825-4	.NUT, SELF-LOCKING, SL UHH,UHV	EA	1
346	10	PAOZZ	5315-00-815-1405	96906	MS24665-151	.PIN, COTTER UHH,UHV	EA	2
346	11	PAOZZ	5306-00-174-4114	88044	AN174H14	.BOLT, CLOSE TOLER UHH,UHV	EA	1
346	12	PAOZZ	1560-00-908-0369	97499	205-001-105-1	.STOP, COLLECTIVE CYLINDER EXTERNAL UHH,UHV	EA	2
346	13	PAOZZ	5306-00-182-1919	88044	AN3H20	.BOLT, MACHINE UHH,UHV	EA	2
346	14	PAOZZ	5310-00-807-1474	96906	MS21042L3	.NUT, SELF-LOCKING UHH,UHV	EA	4
346	16	PAOOO	3040-00-963-0945	97499	205-001-013-1	.CONNECTING LINK UHH,UHV	EA	1
346	18	XAOZZ		97499	205-001-013-3	.TUBE UHH,UHV	EA	1
346	19	PAOOO	5340-00-765-6255	97499	204-001-006-1	.CLEVIS ASSEMBLY UHH,UHV	EA	1
346	20	PAOZZ	3120-00-678-5422	97499	22-006-15-23-16	.BUSHING, SLEEVE UHH,UHV	EA	2
346	21	PAOZZ	3120-00-269-4453	97499	47-140-252-3	.BEARING, PLAIN, ROD END UHH,UHV	EA	1
346	22	PAOZZ	5310-00-167-1302	88044	AN316-7R	.NUT, PLAIN, HEXAGON UHH,UHV	EA	1
346	23	PAOZZ	5306-00-182-1800	88044	AN174-20A	.BOLT, MACHINE UHH,UHV	EA	1
346	24	PAOZZ	5306-00-182-1799	88044	AN174-17A	.BOLT, MACHINE UHH,UHV	EA	3
346	25	PAOZZ	5310-00-857-5557	96906	MS21045L4	.NUT, SELF-LOCKING, HEXAGON UHH,UHV	EA	10
346	26	PAOZZ	5306-00-151-1415	88044	AN4-21A	.BOLT, MACHINE U/O PN 205-001-002-3,-5,-7,-11 & -13 UHH,UHV	EA	4